

Master Electrical Component List

Name	Location
C142 (8 cavities)	Forward lamp wiring harness to the right headlamp wiring harness, behind the headlamp
C181 (10 cavities)	IP wiring harness to the engine wiring harness, on the left side of the engine compartment, on the front of the strut tower
C200 (56 cavities)	IP wiring harness to the body wiring harness, behind the right side of the IP, near the shroud
C201 (48 cavities)	IP wiring harness to the steering column wiring harness, behind the IP on the right side of the steering column
C204 (22 cavities)	IP wiring harness to the body wiring harness, behind the right side of the IP, near the shroud
C205 (4 cavities)	IP wiring harness to the SIR coil wiring harness, behind the IP, on the right side of the steering column
C215 (2 cavities)	IP wiring harness to the SIR coil wiring harness, behind the IP, on the right side of the steering column
C216 (2 cavities)	IP wiring harness to the IP inflator module wiring harness, behind the IP, on the right side of the steering column
C240 (10 cavities)	IP wiring harness to the front floor console wiring harness, behind the front end of the console
C242 (3 cavities)	IP wiring harness to the ashtray wiring harness, behind the ashtray
C290 (1 cavity)	IP antenna to the body harness antenna lead, behind the right side of the IP, near the base of the A pillar (kick panel)
C301 (40 cavities)	Body wiring harness to the left front door wiring harness, behind the trim at the base of the A-pillar
C302 (40 cavities)	Body wiring harness to the right front door wiring harness, behind the trim at the base of the A-pillar
C311 (6 cavities)	Body wiring harness to the driver seat wiring harness, below the driver seat
C312 (Cavities)	Seat wiring harness to the seat back wiring harness below the drivers seat
C325 (2 cavities)	Body wiring harness to console harness under the center console
C355 (8 cavities)	Body wiring harness to the left rear door wiring harness, behind the trim at the base of the B-pillar
C356 (8 cavities)	Body wiring harness to the right door wiring harness, behind the trim at the base of the B-pillar

C142 (8 Cavities) - C356 (8 Cavities)