

DTC P0113	Intake Air Temperature (IAT) Sensor Circuit High Voltage
DTC P0116	Engine Coolant Temperature (ECT) Sensor Performance
DTC P0117	Engine Coolant Temperature (ECT) Sensor Circuit Low Voltage
DTC P0118	Engine Coolant Temperature (ECT) Sensor Circuit High Voltage
DTC P0121	Throttle Position (TP) Sensor Performance
DTC P0122	Throttle Position (TP) Sensor Circuit Low Voltage
DTC P0123	Throttle Position (TP) Sensor Circuit High Voltage
DTC P0125	Engine Coolant Temperature (ECT) Insufficient for Closed Loop Fuel Control
DTC P0128	Engine Coolant Temperature (ECT) Below Thermostat Regulating Temperature
DTC P0130	HO2S Circuit Closed Loop (CL) Performance Sensor 1
DTC P0131	HO2S Circuit Low Voltage Sensor 1
DTC P0132	HO2S Circuit High Voltage Sensor 1
DTC P0133	HO2S Slow Response Sensor 1
DTC P0134	HO2S Circuit Insufficient Activity Sensor 1
DTC P0135	HO2S Heater Performance Sensor 1
DTC P0137	HO2S Circuit Low Voltage Sensor 2
DTC P0138	HO2S Circuit High Voltage Sensor 2
DTC P0140	HO2S Circuit Insufficient Activity Sensor 2
DTC P0141	HO2S Heater Performance Sensor 2
DTC P0171	Fuel Trim System Lean
DTC P0172	Fuel Trim System Rich
DTC P0201-P0206	Injector Control Circuit
DTC P0218	Transmission Fluid Overtemperature
DTC P0230	Fuel Pump Relay Control Circuit
DTC P0243	Supercharger Boost Solenoid Control Circuit
DTC P0300	Engine Misfire Detected
DTC P0325	Knock Sensor (KS) Circuit
DTC P0327	Knock Sensor (KS) Circuit
DTC P0327 or P0332	Knock Sensor Circuit
DTC P0336	Crankshaft Position (CKP) Sensor Circuit
DTC P0341	Camshaft Position (CMP) Sensor Performance
DTC P0401	Exhaust Gas Recirculation (EGR) Flow Insufficient
DTC P0403	Exhaust Gas Recirculation (EGR) Solenoid Control Circuit
DTC P0404	Exhaust Gas Recirculation (EGR) Open Position Performance
DTC P0405	Exhaust Gas Recirculation (EGR) Position Sensor Circuit Low Voltage
DTC P0410	Secondary Air Injection (AIR) System
DTC P0412	Secondary Air Injection (AIR) Solenoid Control Circuit
DTC P0418	Secondary Air Injection (AIR) Pump Relay Control Circuit
DTC P0420	Catalyst System Low Efficiency
DTC P0440	Evaporative Emission (EVAP) System
DTC P0442	Evaporative Emission (EVAP) System Small Leak Detected