

Master Electrical Component List

Name	Location
C101 (20 cavities)	IP wiring harness to the engine wiring harness, on the left side of the engine compartment, on the front of the strut tower
C102 (16 cavities)	Engine wiring harness to the fuel injector wiring harness, on the top of the engine, near the generator
C103 (3 cavities)	IP wiring harness to the engine wiring harness, on the left side of the engine compartment, on the front of the strut tower
C105 (4 cavities) (3.1L)	Engine wiring harness to the coolant fan wiring harness, on the radiator, between the coolant fans
C105 (4 cavities) (3.8L)	Engine wiring harness to the coolant fan wiring harness, on the radiator, between the coolant fans
C108 (5 cavities)	Engine wiring harness to the fuel injector wiring harness, on the top of the engine near the generator
C110 (10 cavities) (3.8L)	Engine wiring harness to the ignition control module wiring harness, on the top of the engine, near the ignition control module
C113 (14 cavities)	Engine to the automatic transaxle harness, on the left side of the engine compartment, on the top of the transmission
C120 (3 cavities)	Lower right side of engine compartment below battery tray
C126 (3 cavities)	Engine wiring harness to the ECT sensor jumper harness, on the top center of the engine, on the intake manifold
C141 (8 cavities)	Forward lamp wiring harness to the left headlamp wiring harness, behind the headlamp

C101 (20 Cavities) - C141 (8 Cavities)