

am8rw00001685

Fig. 26: Identifying Front Parking Brake Cable And Tab
 Courtesy of MAZDA MOTORS CORP.

PARKING BRAKE SWITCH INSPECTION


1. Disconnect the parking brake switch connector.
2. Verify that the continuity is as indicated in the table.
 - If not as indicated in the table, replace the parking brake switch. (See **PARKING BRAKE REMOVAL/INSTALLATION [2WD].**) (See **PARKING BRAKE REMOVAL/INSTALLATION [AWD].**)

○—○: Continuity

Condition	Terminal	
	A	Body ground
Parking brake pedal depressed	○—○	○
Parking brake pedal released	○	○

acxuuw00001059

Fig. 27: Connector Terminal Reference
 Courtesy of MAZDA MOTORS CORP.



ampjw00002631

Fig. 28: Identifying Parking Brake Switch Connector Terminal
 Courtesy of MAZDA MOTORS CORP.